






The direction of the head on the drawing is 180 ° opposite to the actual imaging, and the client register configuration software mirror and flip are required for imaging flipping



Front View



Side View



Rear View